# OET-URC

## UNIVERSAL REMOTE CONTROL

OPERATE:

TV☆VCR☆CABLE☆SATELLITE☆CD☆LD

VCD☆DVD☆TAPE☆TURNER☆AMP

## INSTRUCTION BOOKLET

- WORK WITH MOST MAJOR BRANDS
- EASY SET UP INSTRUCTIONS INSIDE

RIGHT RESERVED TO IMPROVE SPECIFICATIONS WITHOUT NOTICE


# OET-URC

## UNIVERSAL REMOTE CONTROL

OPERATE:

TV☆VCR☆CABLE☆SATELLITE☆CD☆LD

VCD☆DVD☆TAPE☆TURNER☆AMP

## INSTRUCTION BOOKLET

- WORK WITH MOST MAJOR BRANDS
- EASY SET UP INSTRUCTIONS INSIDE

RIGHT RESERVED TO IMPROVE SPECIFICATIONS WITHOUT NOTICE

# USERS' MANUAL FOR

## OET-URC

## I General Description

The universal remote controller is a new model of multi-ftmctional remote control'It features

1. 8 Device Banks: TV I,TV2,VCRI, VCR2.SAT/CABLE, CABLE/SAT and AUX' HiFi,CD,DVD···

2. 4 Operating Modes: Set-up Mode, Quick Search Mode,Auto Search Mode and Display Mode.

3. Transmission and Set-up Indicating LED.

## II Operating Process

1.Set Up Devices

According to the brand code in the attached Device Code List,find out the code of the device that you want to control. Then follow steps as below:

1)Press [SET] key and hold it. Then press the device key that you want to control, such as ITV I],[TV2], [VCRI] or [AUX],etc.

2)The LED will be on at the moment. Release the pressed keys.

3)Enter the 3-digit Device Code.

4)If the entered Device Code is correct,the LED will be off automatically. If the entered Code is incon'ect, the LED will blink twice and keeps being at setup mode (being on).Then pis return to step3).

5)Try if keys on Remote Controller work or not. If most keys work improperly, please find other code in the same brand,repeat 1)-5)till you feel the main keys work well.



Note :In the process of setup,if you want to stop setup work,pis press device key (If no key is pressed in 10 seconds, the remote controller will leave setup mode automatically.)

2.Quick Search

After you have set up several.times the device you want to control,it still does not work(i.e, aie device still cannot be controlled by URC22), or you cannot find the correct code in the Device Code List,you can use Quick Search fanction to find out the correct code. When URC22 has entered into Search Mode, the preset search direction is Forward Search,but you can use [SET] key to switch between Forward Search and Backward Search during search process.

1) Power on the device you want to control. If it's a VCR, it msut be inserted with a tape.

2) Press and hold[SET] key. In themeantime,press the Device Key that you want to control,such as [TVI],[VCR2]etc.

3) The LED will be on at the moment. Release the Pressed keys.

4) Press the [SET]key again and release it. Now the URC-22 unit enters into Quick Search Mode and the LED keeps flashing.

5) Point the URC22 unit to the device and press [POWER] key. If it's VCR/AUX, you can press either [POWER] key or [PLAY]key. See if the device work or not (power off or play).If the device works,turn to step 6).If not,repeat step 5).

6) Then check if other keys such as [CH+/-],[VOL+/-]...can function properly (i.e.if the device can be controlled). Ifnot, return to step 5).

7) Some devices react slowly to [POWER] signal. In search process, you can press[SET]key to switch between Forward/Backward Search to change search direction and find the right code quickly.

8) Whenever you want to leave Search Mode, press Device Key, and the LED will be off.

Note: In Search Mode, besides [POWER] key ([POWER] key and [PLAY] key in the case of VCR/AUX), all other keys can be checked function normally. That means you can test other keys without leaving Search Mode. The URC22 unit will leave Search Mode if no key is pressed for 30 seconds.

3. Auto Search

1) Power on the device you want tocontrol. If it is a VCR, it must be inserted with a tape.

2) Press and hold[SET] key. In themeantime, press and hold [POWER]key for more than 3 seconds and the auto search will begin.

3) Press any key to exit.

4. Brand Code Display

The Control Code is a 3-digit number and the URC22 unit can make all the 3 digits display.

1) Press and hold the [SET]key, in the meantime press the digit that you want to display, such as 1, 2 or 3.

2) Release the [SET]key.

3) Count the time the LED blinks,mad the blinking time i,s the digit. If there is no blink, the digit is zero.

5. Remarks:

Do not press any keys when replacing batteries to avoid missing set-up data.



## BAND Code List

| Brand/Device | TV/TXT | VCR | SAT/DSS | CABLE | HIFI | CD | LDP/CD/DVD | AUX |
|---|---|---|---|---|---|---|---|---|
| AB | | | 812 | | | | | |
| ABC | | | | 452 | | | | |
| ACE | 713 | | | | | | | |
| Admiral | 032,155 | | | | | | | |
| AEON | | | | 502 | | | | |
| Aiwa | 261 | | | | | 581 | 626 | |
| Akai | 005,159,169 | 269,270,271,309 310,356,357 | | | | | | |
| Alba | | | 407 | | | | | |
| Albiral | 001 | | | | | | | |
| Alfa Gold | | | 810,811 | | | | | |
| AlphaStar | | | 826 | | | | | |
| Amstrad | 006 | | 371,372,408 488 | | | | | |
| Anitsch | | 311 | | | | | | |
| Ankaro | | | 373 | | | | | |
| ANSA | | | 821,822 | | | | 671,672,673 | |
| APO | | | | 516 | | | | |
| Apollo | | | 402 | | | | | |
| ASA | 007,009,013,032 094,155,161 | 282 | | | | | | |
| Asiagiant | | | | 501,513 | | | | |
| Astra | | | 372,409,488 | | | | | |
| ASTRX | | | 840 | | | | | |
| ATLE | | | | | | 579 | | |
| Audiosonic | 160 | | | | | | | |
| Aura | | | 430,487 | | | | | |
| Ausind | 008 | | | | | | | |
| Autovox | 004,007,012,014 015,078,079,104 153 | | | | | | | |
| AWA | 033,159,160,189 220 | | | | | | | |
| Baird | 162 | 271,273 | | | | | | |
| Barcom | | | 373 | | | | | |
| Basic Line | 163 | | | | | | | |
| BEKO | 170,226 | | | | | | | |
| Benjamin | | | 468 | | | | | |
| BEST | | | 453 | 498 | | | | |
| Blaupunkt | 010,017,018,020 054,231,232,233 234,236,241 | 272,274,275,312 369 | | | 568 | | | 569(VHS) |
| BPL | 026,160,162,163 | | | | | | | |
| Brionvega | 104,155,164,165 200,201,257 | 276,283 | | | | | | |
| Bruns | 158 | | | | | | | |
| BSR | 016,019,021,253 | | | | | | | |
| Bush(UK) | 022 | 281 | 402 | | | | | |
| Cabletime | 246,247,251 | | | | | | | 524,525 526(CTV) |
| Cambridge | | | 375 | | | | | |

# BAND Code List

| Brand/Device | TV/TXT | VCR | SAT/DSS | CABLE | HIFI | CD | LDVCD/DVD | AUX |
|---|---|---|---|---|---|---|---|---|
| CANAL+ | | | 804 | | | | | |
| Caravell | | | | | | | 822 | |
| Century | 145,146,155 | | | | | | | |
| CGE | 019,023,024,145 151,169,170,231 | 270,277 | | | | | | |
| CGM | 093 | 291 | | | | | | |
| Chaparral | 216 | | 374,410 | | | | | |
| Clarivox | 001,166,167 | | | | | | | |
| Contec | 033,253 | | | | | | | |
| Crosley | 024,025,145,155 231 | | | | | | | |
| CTC Clatronic | 096 | | | | | | | |
| Daewoo | 166,209 | | | | | | 660 | |
| Dansai | | 281 | | | | | | |
| DCS | | | | | | | 642 | |
| Decca(UK) | 002,004,026,028 031,258 | 278 | | | | | | |
| Denca | | | | | | | 665 | |
| Denon | | | | | | 547 | | 554(TUNE) 566(DECK) |
| DNT | | | 409,428,430 487 | | | | | |
| Drake | | | 376,445,446 447,495 | | | | | |
| Dual | 255,258 | 273,279 | | | | | | |
| Dual-Tec | 004,011,019,029 | | | | | | | |
| Dumont | 155 | | | | | | | |
| Dynasat | | | 491,492 | | | | | |
| Eastern | | | | 507,508 509,510 | | | | |
| Echostar | | | 377,378,379 386,409,411 412,457,458 460,461,462 486,800, 827 | | | | | |
| Elbe | 001,171 | 313 | | | | | | |
| Elfe | 188 | | | | | | | |
| Elman | 019,029 | | | | | | | |
| Emerson | 146,155 | 286 | | | | | | |
| EMME ESSE | | | 463,464,465 | | | | | |
| Europhon | 000,004,019,029 038,146 | | | | | | | |
| Eurosky | | | 421 | | | | | |
| Eurostar | | | 465 | | | | | |
| Fenner | 033,193,240 | | | | | | | |
| Fidelity(UK) | 003,034,229 | | | | | | | |
| Filmnet | 202,246 | | | | | | | |
| Finlux | 007,008,009,013 025,026,029,035 094,161,169,221 | 278 | 414,415 | | | | | |



# BAND Code List

| Brand/Device | TV/TXT | VCR | SAT/DSS | CABLE | HIFI | CD | LDVCD/DVD | AUX |
|---|---|---|---|---|---|---|---|---|
| Fisher | 025,036,155,167 170,255 | 280,314,315,316 | | | 529 | 546 | | |
| Force | | | 836 | | | | | |
| Formenti-Phoenix | 003,008,025,037 038,159 | | | | | | | |
| Fortec Star | | | 808,809 | | | | | |
| Fracarro | | | 380,381 | | | | | |
| France Telecom | 266 | | | | | | | |
| Freecom | | | 426 | | | | | |
| FTE | | | 399 | | | | | |
| Fuba | | | 413 | | | | | |
| Funai | 016,160,253 | 359 | | | | | | |
| Funtech | | | 823,824 | | | | | |
| GBC | 002,004,019,025 026,031,033,039 040,041,042 | 281 | | | | | | |
| GEC(UK) | | 278 | | | | | | |
| Geloso | 004,019,025,032 033,039,149,150 | 281 | | | | | | |
| General | | 358 | | | | | | |
| Glucar Record | | | 382,416 | | | | | |
| GMI | | | | 496,515 519,521 | | | | |
| Goldstar | 003,004,043,060 153,172,252,700 701 | 282 | | | | | 633 | |
| Goodmans | 119 | 301 | | | | | | |
| Gorenje | 170,173 | | | | | | | |
| Granada(UK) | 002,004,027,041 044,045,046,047 048,049 | 272,278,283,314 369 | | | | | | |
| Grundig | 003,010,018,020 045,050,051,053 054,056,094 | 272,275,284,361 369 | 383,400,402 404 | | | | | |
| Haitai | | | | | | 548 | 648 | |
| Hanseatic | 025,027,037,044 052,055,258 | 278,285 | | | | | | |
| Hantarex | 000 | | | | | | | |
| Hemmermann | 057 | | | | | | | |
| Hinari | 033,044,058,059 060 | 281,286,287,317 360 | | | | | | |
| Hirschmann | | | 415 | | | | | |
| Hitachi | 004,040,041,042 044,047,055,061 062,063,064,065 066,067,068,174 221,222,710 | 273,281,285,288 | 483,828,829 | | 530 | | | |
| Hotel TV | 704 | | | | | | | |
| HTS | | | 827 | | | | | |
| Hughes | | | 828,829 | | | | | |
| Huth | | | 421,479 | | | | | |
| HWALIN | | | 816 | | | | | |

## BAND Code List

| Brand/Device | TV/TXT | VCR | SAT/DSS | CABLE | HIFI | CD | LDVCD/DVD | AUX |
|---|---|---|---|---|---|---|---|---|
| Hyper | 003,004,033,153 193 | | | | | | | |
| ICX International | | | 417 | | | | | |
| IEEC | | | | 506,514 | | | | |
| Imperial | 019,023,024,145 151,169,170,231 | 277,289 | | | | | | |
| Inkel | | | | | | 541 | | |
| Inno Hit | 000,004,031,043 060,146,175 | | | | | | | |
| Interfunk | 005,027,040,045 046,052,068,070 071,073,075,155 | 278,290 | | | | | | |
| Irradio | 008,039,043,060 153,262 | | | | | | | |
| ITT-Nokia | 005,032,033,040 041,045,049,069 070,071,072,074 076,162,168,176 177 | 270,273,276,290 291,292,316 | 384,385,418 | | | | | |
| Janco | 249,250 | | | | | | | |
| JBL | | | | | | 523 524 | | |
| JEBSEE | | | | 496 | | | | |
| Jeemon | | | 386 | | | | | |
| Jerrold | | | 454 | 417 | | | | |
| Johansson | | | 387 | | | | | |
| JVC | 077,119,178,179 | 270,273,292,318 319,320,321,328 | | | | 585 | 684 | |
| Kaisui | 163 | | | | | | | |
| Karcher | 159,163,175 | | | | | 549 | | |
| Kathrein | | | 388,389,390 419,469 | | | | | |
| Kendo | 146 | | | | | | | |
| Kennedy | 025,078,079 | | | | | | | |
| Kenwood | | | | | 527,531 532,533 534 | 550 580 | 572,636,663 | |
| KOKA | | | | 502,505 | | | | |
| Kortling | 037,155,157 | | | | | | | |
| Legend-V | | | | | | 650 | | |
| Lenco | 033,039,183,238 239,240 | 325,355 | 423,426,480 481,482 | | 595,596 597,598 599,600 601 | 060 549 | | 585,586 587,588 589,590 591,592 593,594 cd) |
| Lenoir | 004 | | | | | | | |
| LEON | | | | 499 | | | | |
| Loewe Opta | 052,081,155,156 189,213,242 | 272,278,369 | | | | | | |
| Logik | 028 | 287,322,360 | | | | | | |
| Luma | 032,082 | 322 | | | | | | |



## BAND Code List

| Brand/Device | TV/TXT | VCR | SAT/DSS | CABLE | HIFI | CD | LDVCD/DVD | AUX |
|---|---|---|---|---|---|---|---|---|
| Luxor | 005,045,047,055 068,083,084,095 096,097,162,177 | 285,291 | 384,391,392 | | | 528 | | |
| Macab | | | 420 | | | | | |
| Macom | | | 444 | | | | | |
| Magnadyne | 000,019,025,029 057,147,149,150 155 | | | | | | | |
| Magnafon | 000,003,008,029 030 | | | | | | | |
| Magnasonic | | 291 | | | | | | |
| Magnavox | | | 477,830,831 | | | 553 576 604 | 571 | |
| Marantz | 026,027 | 272,278,301 | | | | | | |
| Maspro | | | 388,393,402 490 | | | | | |
| Matsui | 004,006,028,041 088,182 | 287,322,332 | | | | | | |
| Maximal | 058 | | | | | | | |
| Melectronic | 255 | | | | | | | |
| Memorex | | 282,314 | | | | | | |
| Metz | 016,053,089,090 091,155,180,183 | 272,275,294,369 370 | 383 | | | | | |
| Micromega | | | | | | | | |
| MINA | | | 494 | | | | | |
| Minerva | 010,018,045,051 053 | 272,275,369 | 383,400,484 | | | | | |
| Mission | | | | | | 553 | | |
| Mitsubishi | 044,052,092,119 154,155,181,182 707 | 278,281,293,320 362,751 | 489 | | | | 662 | |
| Mivar | 000,003,093,094 095, ,599 | | | | | | | |
| Morgans | | | 421 | | | | | |
| Multisystem | 159 | | | | | | | |
| Multitech | 096,170,172 | 281,325 | | | | | | |
| Murphy(UK) | 041 | | | | | | | |
| NAD | | 363 | | | | | | |
| NEC | 184 | 273,313,320 | 422,478,493 | | | 551 | | |
| Neckermann | 004,026,044,055 082,097,170 | 270,272,273,278 285,286,369 | 421 | | | | | |
| N.E.I. | 166 | | | | | | | |
| Network | | | 394 | | | | | |
| Nobliko | 003,008,029,051 146 | 272,369 | | | | | | |
| NOKIA | 029 | | 720,807 | | | | | |

# BAND Code List

| Brand/Device | TV/TXT | VCR | SAT/DSS | CABLE | HIFI | CD | LDVCD/DVD | AUX |
|---|---|---|---|---|---|---|---|---|
| Nordmende | 065,067,075,098 099,101,101,102 103,104,134,185 186,222 | 270,273,279,292 295,296,297,318 319,321,323,324 326,327,328,329 330 | | | 535,549 | | | |
| OAK | | | | 500 | | | | |
| Obritech | | | 426 | | | | | |
| Oceanic(F) | 005,040,105,106 107 | | | | | | | |
| Onces | 004 | | | | | | | |
| Onkyo | | | | | 536,537 | 613 614 615 616 | | |
| Orion | 006,016,028,057 088,103,109,187 188,193,253 | 286,322,331,332 333,360 | | | | | | |
| Osaki | | 282 | | | | | | |
| Otto Versand | 025,027,044,052 055 | 278,285 | | | | | | |
| Pace | | | 394,395,400 402,465,814 815 | | | | | |
| Pael | 003,008 | | | | | | | |
| Palcom | | | 396 | | | | | |
| Palladium | 197 | 271,356 | 421 | | | | | |
| Palsat | | | 423 | | | | | |
| Panasat | | | 819 | | | | | |
| Panasonic | 001,003,019,037 040,106,110,111 112,114,190,241 | 274,290,312,354 | 473,832 | | 538 | | 573,574,629 639 | |
| Pansat | | | 455 | | | | | |
| Paragon | | | | 506 | | | | |
| Penney | | 313 | | | | | | |
| Pentax | | 288 | | | | | | |
| Philco | 019,023,024,025 151,155,169,170 231 | | | | | | | |
| Philex | 229 | | | | | | | |
| Philips | 003,026,027,046 073,113,115,155 191,192,193,194 223,266,230,242 | 278,302,334,335 336,369 | 402,424,425 477,803,830 831 | | | 552 553 579 604 | 598, | 560(EQ) 561(PIP) 562(TAPE) 565(TUNE) 567(DCC) |
| Phonola | 175 | 278,335 | | | | | | |
| Pilot | 721 | | | | | | | |
| Pioneer | 000,027,067,243 | 278,320,334,336 363,364,365 | 474 | | 545 | 554 555 610 | 571,658 | |
| Polestar | 214 | | | | | | | |
| Prandoni-Prince | 008,032,146 | | | | | | | |
| Praxis | 217 | | | | | | | |
| Premier | | | 802 | | | | | |



# BAND Code List

| Brand/Device | TV/TXT | VCR | SAT/DSS | CABLE | HIFI | CD | LDVCD/DVD | AUX |
|---|---|---|---|---|---|---|---|---|
| Primestat | | | 454 | | | | | |
| Prosat | 001 | | 405,451,479 | | | | | |
| Proton | | | | | | 553 | | |
| PYE | | 320 | | | | | | |
| Quartz | | 314 | | | | | | |
| Quelle | 004,005,007,008 009,010,013,026 027,028,045,050 051,052,069,094 153,221,231,232 234,235,236,253 | 272,275,278,286 288,369 | 383 | | | | | |
| Radiola | 242 | | | | | | | |
| Radiotone | | | | | | 549 | | |
| Radix | | | 409,428,430 487 | | | | | |
| Rank(UK) | 022 | | | | | | | |
| RBM(UK) | 022,094 | | | | | | | |
| RCA | 204,210,211 | 349 | 450,818,835 | | | | 602,661,667 | |
| RC-AK | | | 456 | | | | | |
| Rediffusion(UK) | 005,041,116 | | | | | | | |
| | | | | | | | | |
| REX | 011,021,032,078 079,118 | 273,292,319 | | | | | | |
| Roadstar | 039 | | | | | | | |
| ROTEL | | | | | | 553 582 583 | | 584(TAPE) |
| SABA | 000,065,067,075 085,098,099,100 103,117,155,185 186,222,224 | 270,273,279,292 295,318,319,321 326,337,338 | | | | | | |
| SAE | | | | | | 553 | | |
| Saisho | 004,006,028,088 182,244 | 266,287,322,332 360 | | | | | | |
| Sakura | | | 397,398 | | | | | |
| Salora | 005,047,048,055 066,068,069,076 082,086,097,162 177,195,249,250 267,368 | 283,286,314 | 391,418 | | | | | |
| Sambers | 000,004,008,029 030,043 | | | | | | | |
| Samsung | 026,033,043,159 160,170,175,212 215,702,703,716 | 289 | 459,475,476 | | | | 637,666 | |
| Sansui | | 320 | | | | 551 | | |
| Sanyo | 013,031,044,074 119,120,121,122 123,162,167,170 182,195,205 | 291,314,316,339 | | | 539 | 554 606 | | |
| SAT 100 | | | 372,488 | | | | | |
| Sateco | | | 426 | | | | | |

# BAND Code List

| Brand/Device | TV/TXT | VCR | SAT/DSS | CABLE | HIFI | CD | LD/VCD/DVD | AUX |
|---|---|---|---|---|---|---|---|---|
| Schneider | 004,011,015,019 025,036,038,255 258,262 | 278,281,289 | | | | | | |
| Scientific Atlanta | | | 452 | | | | | |
| Sears | | 315 | | | | | | |
| SEG | 096 | 281,289 | | | | | | |
| Seleco | 011,058,078 | 309 | | | | | | |
| Senta | | 277 | | | | | | |
| SET | | | 825,837,838 839 | | | | | |
| Sharp | 044,054,119,124 195,198,225,227 | 301,302,341 | | | 531 | 550 566 | 628 | |
| Sherwood | | | | | 540,541 577,578 | | | |
| Shinton | | 356 | | | | | | |
| SHOV | 033 | | | | | | | |
| Siarem | 000,025,029,155 | | | | | | | |
| Sicatel | 001 | | | | | | | |
| Siemens | 010,231,232,233 234,236 | 272,275,291,369 | 583 | | | | | |
| Siesta | 254 | | | | | | | |
| Silver | 160 | | | | | | | |
| Singer | 025,029,147,149 155 | | | | | | | |
| Sintrack | | | 427 | | | | | |
| Sinudyne | 006,016,025,026 029,057,109,125 155,192,197,253 | 278,287 | | | | | | |
| Skyglant | | | | 511,512 | | | | |
| Skymaster | | | 479 | | | | | |
| Sony | 028,119,126,127 128,129,130,182 199,228,260,705 | 298,299,340,342 343,344,367,750 | 472,834 | | 617 | 556 557 575 607 | 575,631,657 | 563(TAPE) 575(CDV) 618(TUNE) |
| Star | | | 470 | | | | | |
| Stern | 078 | | | | | | | |
| Strong | | | 399,423,426 480 | | | | | |
| STS | | | 393 | | | | | |
| STV | | | 413 | | | | | |
| Sun Moon Star | | | 813 | | | | | |
| Sylvania | | | | | | | 553 604 | |
| TADA | | | | 448,523 | | | | |
| Tadiran | | | 817 | | | | | |
| Taicom | | | | 502 | | | | |
| Tai Wah | 219,219 | | | | | | | |
| Tandberg | 180,253,266 | 322 | | | | | | |
| Tantec | | | 396 | | | | | |
| Tatung | 002,004,026,028 031,131 | 278 | | | | | 659 | |
| Tay Shoen | | | | 506,517 | | | | |



BAND Code List

| Brand/Device | TV/TXT | VCR | SAT/DSS | CABLE | HIFI | CD | LD/VCD/DVD | AUX |
|---|---|---|---|---|---|---|---|---|
| Teac | | | | | | 608 611 | | |
| Technics | | | | | 542 | 558 609 | | |
| Technisat | | | 409,428,429 430,431,487 | | | | | |
| Technosat | | | 467 | | | | | |
| Technovision | 263 | | | | | | | |
| Tedelex | | | 466 | | | | | |
| Teknika | | | 471 | | | | | |
| Tele +1 | 245 | | | | | | | |
| Teleavia | 186 | | | | | | | |
| Telefunken | 067,075,098,132 133,134,135,140 185,186,231,235 | 270,273,279,292 316,319,321,323 330,345,346,347 | | | | | | |
| Telemax | | | 432 | | | | | |
| Telemeister | | 399 | 398,409,428 430,469,487 | | | | | |
| Teleservice | 203,246 | | | | | | | |
| Thomson | 065,067,075,078 098,100,103,185 186,222 | 270,273,279,292 316,323,324,328 | | | | | 668 | |
| Thorn-Ferguson | 001,135,136,137 140,144,148,152 160,196,229,255 | 270,273,300,303 304,305,306,308 319,329,330,348 368 | 394,395,400 401,402,433 485 | | | | | |
| TMK | | 286 | | | | | | |
| Toshiba | 022,044,094,119 138,139,141,142 | 273,292,307 | 442,444,833 | 522 | | | 671,648 | |
| TPS | | | 865 | | | | | |
| Trans | | | | 497,516 520 | | | | |
| Uher | 011,012,036,037 038,076,255 | 273,289 | | | | | | |
| Ultravox | 003,025,092,096 146,155 | 276 | | | | | | |
| Uniden | | | 402,404,406 443,808,821 | | | | | |
| United Satellite | | | 440 | | | | | |
| Universum | 064,168,221 | | | | | | | |
| Univox | 001 | | | | | | | |
| US Electronics | | | 417 | | | | | |
| Vector | | 313 | 438,487 | | | | | |
| Vegavox | 169 | | | | | | | |
| Victor | | 318,328,366 | | | | | 665 | |
| Video | | 313 | | | | | | |
| Videocon | 033,138,141,715 | | | | | | | |
| Viewstar | | | 477 | | | | | |
| Vortic Star | | | 801 | | | | | |
| Voxson | 002,155 | | | | | | | |
| Vtech | | | 434 | | | | | |
| Watson | 007 | | | | | | | |

## BAND Code List

| Brand/Device | TV/TXT | VCR | SAT/DSS | CABLE | HIFI | CD | LDVCD/DVD | AUX |
|---|---|---|---|---|---|---|---|---|
| Watt Radio | 001,003,025,029 030,057 | | | | | | | |
| Wega Color | 119,143 | | | | | | | |
| White Westinghouse | 003,037,159 | 276,282 | | | | | | |
| Winer | | | 387,449 | 501 | | | | |
| WISI | | | 409,420,435 436,437,438 439 | | | | | |
| WISO | | | | 503,504 | | | | |
| Xenon | | 322 | | | | | | |
| Yamaha | | | | | 543,544 | 612 | | |
| Yoko | 004,159 | | | | | | | |
| Zanussi | 078 | | | | | | | |
| Zehnder | | | 390 | | | | | |
| Zenith | 203,237 | | 441,444,445 446,447 | | | | 570 | |
| Others | 206,207,206,264 265 | 350,351,352,353 | 620 | | | | 674 | 625 (A-BSwitch) |
| 山 | | | | | | | 627 | |
| 白 | | | | | | | 627 | |
| 天 | | | | | | | 643 | |
| 北京(BEIJING) | 706,711 | | | | | | | |
| 步步高(BBK) | | | | | | | 654 | |
| 金科(Gymco) | | | | | | | 646 | |
| 科 | 160 | | | | | | | |
| 长虹(Chang Hong) | 141,175,711,717 718,719 | | | | | | 649 | |
| 长城 | 711 | | | | | | | |
| 春 | 711 | | | | | | | |
| 长风(Solive) | | | | | | | 641 | |
| 长 | 711 | | | | | | | |
| 长 | 711 | | | | | | | |
| 长 | 711 | | | | | | | |
| 创维(Chuangwei) | 709,711 | | | | | | | |
| 王牌(TCL) | | | | | | | 632 | |
| 多 | | | | | | | 627 | |
| 视 | 708 | | | | | | | |
| 电 | | | | | | | 644,655 | |
| 新科(Shinco) | | | | | | | 647 | |
| 新科(MKT) | | | | | | | 651 | |
| 信 | 033 | | | | | | | |
| 红 | 711 | | | | | | | |
| 中 | 711 | | | | | | | |
| 中 | 711 | | | | | | | |
| 康佳(KONKA) | 706,712,714 | | | | | | | |
| 春 | 708 | | | | | | | |

## BAND Code List

| Brand/Device | TV/TXT | VCR | SAT/DSS | CABLE | HIFI | CD | LDVCD/DVD | AUX |
|---|---|---|---|---|---|---|---|---|
| 先丰(SMC) | | | | | | | 636 | |
| 夏星(Xiaxing) | | | | | | | 652 | |
| 安多(IDALL) | | | | | | | 635,653 | |
| 银河(Yinhe) | | | | | | | 656 | |
| 熊猫(PANDA) | 706 | | | | | | 645 | |
| 康丰 | 706 | | | | | | | |
| 得荣 | 708 | | | | | | | |
| 德三三 | | | | | | | 638 | |
| 福宇 | 175,706 | | | | | | | |
| 黄歌 | 711 | | | | | | | |